



EV CHARGE SOLUTIONS® NACS Holster Conversion Kit

EVCS-NACS-A-01

Instructions for the removal of J1772 Holster and/or installation of NACS Holster on EV Charge Solutions EZ-Pull, Slim and Universal Pedestals.

Kit Includes:

- 1 NACS holster
- 4 screws, 10-32 x ¾" pan head
- 4 screws, #10 x ¾" self drilling/tapping

1. If installed, remove the J1772 holster using a **T25 Torx bit/driver** to remove the 4 screws. Skip this step if not installed.



J1772 Holster

2. Install the NACS holster using included screws and a **T25 Torx bit/driver**. Tighten until there is resistance but DO NOT overtighten.



Included with Kit